

BCH 400 BP Brushcutter



Documents

Engine

Starter assy and clutch

Tank / Frame (High)

Transmission




Illustration Engine

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	3	3960121R	Screw				
2	1	61452028R	Engine cover				
3	1	3055104R	Spark plug				
4	4	3860095R	Screw				
5	1	61450212R	Complete muffler				
6	1	61450242AR	Gasket				
7	2	3801065R	Screw				
8	2	3916006R	Washer				
9	1	3801011R	Screw				
10	1	61450367R	Muffler cover				
11	1	61450442	Complete cylinder				
12	2	61450014R	Piston ring				
13	2	61450013R	Ring				
14	1	61450187R	Piston assy				
15	1	61450127AR	Gasket				
16	4	3860096R	Screw				
17	1	61452001BR	Crankcase assy				
18	1	3050056R	Oil seal				
19	2	3035065R	Bearing				
20	1	61450001AR	Crankshaft				
21	1	3028020R	Key				
22	1	50110044R	Bearing				
23	1	3050057R	Oil seal				
24	1	61450443	Gasket set				
25	2	3801009	Screw				
26	2	3916005R	Washer				

Illustration Starter assy and clutch




Illustration Starter assy and clutch

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61452042R	Starter assy				
2	1	61450193AR	Clutch driver				
3	1	61450229AR	Starter pulley				
4	1	61450044AR	Starter spring				
5	6	3916005R	Washer				
6	10	3801013R	Screw				
7	1	61452083R	Flange				
8	6	3819006R	Washer				
9	2	61450070R	Pin				
10	2	61450072R	Washer				
11	1	61450277R	Clutch				
12	2	61450071R	Washer				
13	1	50010148R	Nut				
14	1	3833080R	Washer				
15	1	61450310R	Flywheel				
16	1	61450037R	Cable				
17	1	2501026BR	Ignition coil				
18	1	61450370R	Spark plug cap				

Illustration Tank / Frame (High)




Illustration Tank / Frame (High)

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61330040AR	Screw				
2	1	61450444	Air filter cover				
3	1	61450061R	Air filter				
4	2	3801012	Screw				
5	6	3916005R	Washer				
6	1	61450445	Air filter support				
7	1	3918010R	Washer				
8	1	3801011R	Screw				
9	1	2318624R	Carburetor				
10	1	61450054AR	Gasket				
11	1	3801015R	Screw				
12	1	61450053AR	Insulator				
13	1	61450052AR	Gasket				
14	1	094600450R	Fuel filter				
15	1	61450363R	Tank cap				
16	1	61452050R	Tank assy				
17	1	61450230R	Tank shield				
18	2	3801013R	Screw				
19	1	61450380R	Harness				
20	1	61450381R	Frame assembly				
21	1	BF000017R	Engine support				
22	3	BF000018R	AV-mount				
23	1	61450443	Gasket set				




Illustration Transmission

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	BF000001R	Complete handle				
2	1	BF000010R	Throttle cable				
3	1	61450199R	Starter case				
4	1	BF000002R	Clutch drum				
5	1	BF000003R	Hose				
6	1	BF000004R	Joint				
7	1	61450448	Shaft + joint				
8	1	BF000005R	Tube Ø26				
9	1	BF000008R	Bracket				
10	1	BF000029R	Guard kit				
11	1	BF000009R	Blade				
12	1	61450318R	Complete knob				
13	1	61450441R	Bevel gear				
14	1	BF000007R	Nut				